

BLIND NUTS CONT.

Blind nuts for 52-54 Ford and Mercury wagons

303 stainless steel, knurled shank, highly polished, perfect.

Description	Item number	price
This set is designed to replace all your blind nuts when new wood is installed. 54 pieces. These nuts have a .800 head dia. And a 1/4-20 thread.	075254-93	\$225.00

Blind nuts for your 55 thru 67 Ford of Mercury wagon

Call and we can set you up with a replacement set.

Blind nuts for 1946-48 Chevrolet wagons

and maybe some other General motors wagons

303 stainless steel, knurled shank, highly polished, perfect.

Description	Item number	price
1946-48 Chevrolet blind nut. 5/16-18 thread, .740 head dia	044648-17	\$4.35
1946-48 Chevrolet blind nut. 1/4-20 thread, .800 head dia. Used for door hinge screws	044648-18	\$4.35
1946-48 Chevrolet blind nut set. 12 of the 5/16s and 8 of the 1/4 blind nuts. 20 pieces total.	044648-19	\$82.00

Tube Screws for 42-48 Chevrolet wagons

and maybe some other General motors wagons.

303 stainless steel, correct head and tube dia.

Description	Item number	price
42-48 Chevrolet tube screws. 12 per car needed. Sold individually	064248-20	\$4.50 ea.

Tube Screws for 49 Chevrolet wagons

and maybe some other General motors wagons.

303 stainless steel, correct head and tube dia.

Description	Item number	price
49 Chevrolet tube screws. These are longer than the 42-48. 8 per car needed. Sold individually	0649-21	\$4.75 ea.

Blind nuts for 1949 and 50 MOPAR wagons

303 stainless steel, knurled shank, highly polished, perfect.

Description	Item number	price
1949-50 MOPAR blind nut. Used on Plymouth, Dodge, Desoto and Chrysler. 5/16-18 thread, .960 head dia.	034950-09	\$4.65
1949-50 MOPAR blind nut set . 26 pieces	034950-16	\$115.00
1949-50 MOPAR hardware. 3" pan head zinc plated screw. Cut to fit	064950-71	\$1.35
1949-50 Mopar hardware set. 26 pieces of 3" pan head screws	064950-72	\$30.00